

# — AG400 —

## GRAFFITI WASH

### TECHNICAL DATA SHEET

Rev. 11-2019



#### System Overview

ACP<sup>®</sup> AG400 Graffiti Wash is the graffiti remover designed to work in conjunction with the A C P Anti-Graffiti Solution System and allows a property owner to maintain a graffiti-free environment; one in which graffiti is removed without leaving any trace of graffiti when used per manufacturer's instructions. AG400 Graffiti Wash is sprayed over the graffiti tag and agitated with a nylon or brass brush. Once the graffiti is removed from the surface, use a low pressure hose or sprayer with clean water to rinse cleaned area.

AG400 Graffiti Wash is packaged in nonaerosol spray bottles, 1 gallon cans, 5 gallon pails, and 55 gallon drums.

#### System Strengths

- Bio-degradable
- Safe for ground water
- Recyclable
- pH 7.5
- Non-flammable
- No blasting, hot water, or high-pressure wash equipment required.

#### AMERICAN COATING PRODUCTS (ACP) ANTI-GRAFFITI SOLUTION SYSTEM: AG400 GRAFFITI WASH

##### WORK-SITE PREPARATION

Ensure people, vehicles, property, foliage, and surfaces that are not to be coated, and that may be subject to splash, fumes, and wind drift of product are protected.

Ensure fresh air entry and cross ventilation during cleaning process. Extinguish all flames, pilot lights and any other potential sources of ignition during cleaning process.

##### SUBSTRATE PREPARATION

Substrate should be thoroughly dry.

##### EQUIPMENT

Spray bottle or low pressure sprayer (Hudson type).

##### SUCCESSFUL REMOVAL TIPS

- Proper surface preparation (Dry)
- Beware of environmental conditions
- Use clean equipment, no cross-contamination
- Follow removal instructions
- Be aware of wind conditions & surrounding vehicles, homes, and businesses
- Proper clean-up, storage, and disposal of products and equipment

##### CLEAN UP & DISPOSAL

Clean manual sprayer & low pressure sprayer by thoroughly rinsing with cool, clear water.

Dispose of unused product and container in accordance with local, state, and federal regulations.

**Technical Data****ACP AG400 Graffiti Wash (Graffiti Remover)**

Form:	Clear Liquid
Specific Gravity:	1.0245
WT/GAL:	8.5304
VOC Content:	996 g/L
Flash Point:	195.8°F / 91.0°C
Shelf Life:	2 years in a tightly sealed unopened container

*Meets SCAQMD Requirements*

**First Aid Information****Eye Contact:**

- Rinse immediately with plenty of water for 15 minutes
- Do not apply neutralizing agents
- Consult a doctor/medical service if irritation persists

**Skin Contact:**

- Wash immediately with plenty of water and soap for 15 minutes.
- Remove clothing before washing
- Do not apply (chemical) neutralizing agents
- Consult a doctor/medical service if irritation persists

**After Inhalation:**

- Remove the victim into fresh air
- Unconscious: maintain adequate airway and respiration
- Consult a doctor/medical service if breathing problems develop

**After Ingestion:**

- Immediately give plenty of water to drink
- Never give water to an unconscious person
- Consult a doctor/medical service if nausea or sickness persists

**24 Hour Emergency Information:**

Domestic Shipments and to Canada:  
800-633-8253

International Shipments: 801-629-0667

**SAFETY INFORMATION**

Eye Protection:	Wear safety glasses.
Hand Protection:	Wear solvent resistant gloves (rubber).
Skin Protection:	Protective clothing (no exposed skin).

**REMOVAL INSTRUCTIONS**

1. When removing graffiti from affected area, always start at the top of the graffiti and work downward. Spray AG400 Graffiti Wash onto the graffiti. Let Graffiti Wash work for you by allowing it to wash the graffiti down-ward off the vertical surface. Press the spray trigger with sufficient pressure to force Graffiti Wash into the valleys between any ridges. Spray the area as closely as necessary to clean out any pockets of trapped graffiti. Let Graffiti Wash stand on surface for 10 to 15 seconds to allow Graffiti Wash to cut graffiti. Note: Removal area should be of an adequate size so that overspray or splatter will be contained.
2. Graffiti Wash will remove some graffiti on initial contact; however, some graffiti may require Graffiti Wash to be left on a longer time before you can begin to loosen and remove it. If Graffiti Wash does not begin to loosen the graffiti immediately, wait 1 minute before agitating the graffiti with a nylon or brass brush. Work Graffiti Wash into the graffiti by scrubbing or agitating it as necessary with a nylon or brass brush until all graffiti is loosened. Note: Do not use steel or stainless steel brushes. These brushes may damage the coating.
3. Reapply Graffiti Wash as in Step 1 to the entire area to ensure that all of the graffiti is completely loosened. This will liquefy the graffiti and improve the removal. If necessary, use a nylon or brass brush to remove any faint shadowing of graffiti. Rinse again with Graffiti Wash. Inspect for complete removal of graffiti.
4. After the surface is completely clean of graffiti, rinse the surface with water. If the surface is not completely clean, repeat steps 1,2 and 3 before rinsing with cool, clear water. A low-pressure water source such as a garden hose or backpack sprayer is usually adequate although moderately high pressure can improve removal of paint that may be trapped on surface pores.
5. Water deactivates Graffiti Wash. If further removal is needed because some minor shadowing was not removed during original Graffiti Wash application, make sure the surface is thoroughly dry before applying additional Graffiti Wash. If you need to apply Graffiti Wash again, wait until the surface is completely dry.

**NOTE: Do not dilute Graffiti Wash.**